



## Setting Delay Function on Sporting Clays Course

### To Set a Delay for a True Pair

Before inserting a key:

- Press the trap 2 button to increase the delay.
- Press the trap 1 button to decrease the delay.

Insert your key.

When ready press the Doubles button.



### To Set a delay for a Following Pair

Before inserting a key:

- Press trap 2 button to set delay for first target.
- Press trap 1 button to decrease delay.
- Press the Doubles button.
- Set delay for second target by pressing button 2
- Decrease the delay by pressing button 1.

Insert your Key.

When ready press the Doubles button.



Capitol City Gun Club

3590 Arrowhead Drive Carson City NV 89706-2006 (775) 882-9904

[www.capcityclays.com](http://www.capcityclays.com) info@capcityclays.com